






Ref.Nu	Q.ty	Item number	Description	Technical bulletin
1	1	50170010R	Manifold	
2	1	094600103	Band	
3	1	3055101	Spark plug	
4	1	50170186R	Gasket	
5	1	50170189R	Muffler	
6	3	3860117R	Screw	
7	2	004000015R	Piston ring	
8	1	50110047R	Piston pin	
9	2	004900061R	Ring	
10	1	50120034	Piston assy Ø40	
11	1	50172021	Complete cylinder	
12	2	50110043R	Spacer	
13	1	50110044R	Bearing	
14	1	3050022R	Seal ring	
15	1	094000006R	Bearing	
16	1	3050024R	Seal ring	
17	1	50050016R	Cover	
18	4	3801047	Screw	
19	1	50110045R	Crankshaft	





Ref.Nu	O.ty	Item number	Description	Technical bulletin
1	1	50172005R	Starter assy	
2	1	50170017R	Handle	
3	1	50070123R	Starter rope	
4	1	005000361	Washer	
5	1	3833080	Washer	
6	1	50050073R	Spring	
7	1	004000142	Nut	
8	1	50170153R	Starter pulley	
9	1	50160024	Screw	
10	4	3960115R	Screw	
11	2	3960075	Screw	
12	2	006000315	Washer	
13	2	3916004	Washer	
14	1	50170144BR	Ignition coil	
15	1	50170090R	Cable	
16	1	50072029	Pawl	
17	1	50170015R	Flywheel	
18	1	50170154R	Spring	
19	1	50170155R	Insert	
20	1	50050126	Spark plug cap	
21	1	50050127	Spring	
22	1	50172032	Labels set	
23	1	2304017	Wrench 13x16	



Ref.Nu	Q.ty	Item number	Description	Technical bulletin
1	1	50052005R	Tank cap	
2	1	3049025	O-ring	
3	11	3960115R	Screw	
4	1	50170071R	Cover	
5	5	50070067A	Rod	
6	1	50170004R	Gasket	
7	1	50170042R	Spike	
8	2	3960099R	Screw	
9	1	097000229R	Breather valve	
10	2	50050052	Stud	
11	1	50050049R	Hose	
12	3	3960074	Screw	
13	1	50170051AR	Oil pump	
14	1	094600369R	Guard	
15	5	3860097	Screw	
16	5	50050067	Spacer	
17	1	50172009R	Crankcase assy	
18	1	50170149R	Oil filter	
19	1	50170060AR	Lever	
20	1	50170062R	Plate	
21	1	50160024	Screw	
22	1	3960070AR	Screw	
23	1	005000347A	Grommet	
24	1	50170032R	Deflector	
25	1	50170061R	Spring	
26	2	3933100R	Nut	
27	1	50170132R	Support	
28	1	50050056BR	Gasket	
29	1	50170036R	Air filter	
30	1	50170079AR	Cover	
31	1	50110007R	Knob	
32	1	2318755CR	Carburetor WT-780D	
33	1	50172020R	Cover	
34	1	50070126R	Spacer	
35	1	50170033R	Guard	




Ref.Nu	Q.ty	Item number	Description	Technical bulletin
1	1	50052005R	Tank cap	
2	1	3049025	O-ring	
3	1	50170024R	Cover	
4	1	50050096AR	Lever	
5	1	097000028R	Spring	
6	1	50170067R	Throttle	
7	1	50060012	Air purge	
8	1	50170012R	Throttle rod	
9	1	094600450R	Fuel filter	
10	1	50170152R	Hose	
11	1	094500577A	Valve	
12	1	094500575R	Spring	
13	1	50050071	Breather valve	
14	3	50010061R	Shock absorber	
15	3	50050047AR	Spring	BT4-101-10/09
16	1	3918010R	Washer	
17	3	3960115R	Screw	
18	3	50170034R	Support	
19	7	3960099R	Screw	
20	1	50172007R	Tank	
21	1	50170026R	Handle	
22	1	50170224R	Hose	
23	1	50170121R	Sheath	
24	1	50060014R	Hose	
25	1	50050123R	Strap	



Ref.Nu	Q.ty	Item number	Description	Technical bulletin
1	1	50170065R	Chain cover assy	
2	1	50170040R	Guard	
3	1	095000219R	Spring	
4	1	50010088AR	Spring	
5	2	3960070AR	Screw	
6	1	50050125R	Plate	
7	1	50050039	Brake band	
8	1	097000146	Lever	
9	1	50050064	Pin	
10	1	004000352	Washer	
11	2	50010148R	Nut	
12	1	094500029	Spring	
13	1	094000129AR	Clutch	
14	1	50060033A	Clutch .325	
15	1	004400285	Washer	
16	1	50060008R	Worm gear .325	
17	1	50030372	Bearing	
18	1	50162017A	Chain tensioner	
19	1	50170044R	Cover	

WT-780D



16 ■ KIT RIPARAZIONE
REPAIR KIT

Ref.Nu	Q.ty	Item number	Description	Technical bulletin
1	1	094600148	Spring	
2	1	074000240	Adjust.screw	
3	1	095000141	Shutter	
4	3	50010141	Screw	
5	1	094600208	Spring	
6	1	2318753	Shaft	
7	2	2318867	Cap	
8	1	2318837	Screw H	
9	1	2318893	Screw L	
10	1	2318743	Throttle lever	
11	4	035000162	Screw	
12	1	2318191	Cover	
13	1	003300202	Screw	
14	1	003300201	Spindle	
15	1	50050115	Spring	
16	1	2318671	Repair kit	
17	1	2318742	Lever	
18	1	2318751	Bushing	
19	2	50010265	Washer	
20	1	50050107	Cover	
21	1	003300197	Screw	
22	2	2318752	Snap ring	
23	1	2318764	Shaft	
24	1	094600140	Shutter	